



## Sash opening/closing

**The cam catch lever(s) needs to be positioned in the open position. If locking cam catch(s) are fitted, insert the key and turn to lock or unlock. Remove the key and store in a suitable position.**

The sashes must be opened and closed by using the sash lifts/ring pull(s). On no account must the sashes be opened and closed using the external Georgian bars (if fitted). The Georgian bars are a decorative feature only and it is possible that they could become loose or even fall off if used to open and close the sashes.

*WARNING: If the Georgian bars are used as a means for opening and closing sashes, no warranty will be given and any remedial site visits will be chargeable*



## Cleaning

The windows should be cleaned using warm soapy water. On no account should abrasive or solvent based cleaners be used on the window.

